

No.	Description	Profile	Finish	Inventory	
2	3885101	1G Intermediate Switch	Screw Less Plate	Antique Brass with Black Insert	40
	3885102	2G Intermediate Switch	Screw Less Plate	Antique Brass with Black Insert	40
	3885103	1G Blank Plate	Screw Less Plate	Antique Brass with Black Insert	10
	3885104	2G Blank Plate	Screw Less Plate	Antique Brass with Black Insert	30
	3885105	1G Coaxial	Screw Less Plate	Antique Brass with Black Insert	30
	3885107	1G Telecomm Secondary	Screw Less Plate	Antique Brass with Black Insert	40
	3885108	1G Telecomm Master	Screw Less Plate	Antique Brass with Black Insert	40
	3885109	Shaver Socket	Screw Less Plate	Antique Brass with Black Insert	45
	3885111	1G Data (Cat 6)	Screw Less Plate	Antique Brass with Black Insert	30
	3886117	1G 13A Unswitched FCU	Screw Less Plate	Antique Brass with Black Insert	7
	3886118	1G 13A Unswitched FCU + Neon	Screw Less Plate	Antique Brass with Black Insert	10
	3886119	1G 13A Switched FCU	Screw Less Plate	Antique Brass with Black Insert	39
	3886120	1G 13A Switched FCU + Neon	Screw Less Plate	Antique Brass with Black Insert	39
	3886121	Fan Isolator	Screw Less Plate	Antique Brass with Black Insert	29
	3887115	1G 45A Switch (+ Neon)	Screw Less Plate	Antique Brass with Black Insert	49
	3887116	2G 45A Cooker Ctrl (+ Neon)	Screw Less Plate	Antique Brass with Black Insert	29
	3888101	1G 13A	Screw Less Plate	Antique Brass with Black Insert	143
	3888102	1G 13A + USB	Screw Less Plate	Antique Brass with Black Insert	41
	3888103	2G 13A	Screw Less Plate	Antique Brass with Black Insert	47
	3888104	2G 13A + USB	Screw Less Plate	Antique Brass with Black Insert	27
	3888105	1G Face Plate	Screw Less Plate	Antique Brass with Black Insert	76
	3888106	2G Face Plate	Screw Less Plate	Antique Brass with Black Insert	54
	3889106	3G 2W Dimmer	Screw Less Plate	Antique Brass with Black Insert	42
	3889107	1G 2W Dimmer	Screw Less Plate	Antique Brass with Black Insert	73
	3889108	2G 2W Dimmer	Screw Less Plate	Antique Brass with Black Insert	49
	3889109	4G 2W Dimmer	Screw Less Plate	Antique Brass with Black Insert	59
	3889111	2G 2W Switch	Screw Less Plate	Antique Brass with Black Insert	2
	3889113	4G 2W Switch	Screw Less Plate	Antique Brass with Black Insert	23
	3889114	6G 2W Switch	Screw Less Plate	Antique Brass with Black Insert	5
	3	3886127	1G 13A Unswitched FCU	Flat Plate	Antique Brass with Black Insert
3886128		1G 13A Unswitched FCU + Neon	Flat Plate	Antique Brass with Black Insert	8
3886130		1G 13A Switched FCU + Neon	Flat Plate	Antique Brass with Black Insert	187

	3887125	1G 45A Switch (+ Neon)	Flat Plate	Antique Brass with Black Insert	4
	3888111	1G 13A	Flat Plate	Antique Brass with Black Insert	173
	3888112	1G 13A + USB	Flat Plate	Antique Brass with Black Insert	196
	3888113	2G 13A	Flat Plate	Antique Brass with Black Insert	92
	3888114	2G 13A + USB	Flat Plate	Antique Brass with Black Insert	27
	3888115	1G Face Plate	Flat Plate	Antique Brass with Black Insert	43
	3888116	2G Face Plate	Flat Plate	Antique Brass with Black Insert	10
	3889117	1G 2W Dimmer	Flat Plate	Antique Brass with Black Insert	26
	3889118	2G 2W Dimmer	Flat Plate	Antique Brass with Black Insert	127
	3889119	4G 2W Dimmer	Flat Plate	Antique Brass with Black Insert	8
	3889120	1G 2W Switch	Flat Plate	Antique Brass with Black Insert	115
	3889121	2G 2W Switch	Flat Plate	Antique Brass with Black Insert	155
	3889122	3G 2W Switch	Flat Plate	Antique Brass with Black Insert	41
	3889124	6G 2W Switch	Flat Plate	Antique Brass with Black Insert	2
4	3886137	1G 13A Unswitched FCU	Classic	Antique Brass with Black Insert	7
	3886138	1G 13A Unswitched FCU + Neon	Classic	Antique Brass with Black Insert	9
	3886139	1G 13A Switched FCU	Classic	Antique Brass with Black Insert	4
	3886140	1G 13A Switched FCU + Neon	Classic	Antique Brass with Black Insert	7
	3887135	1G 45A Switch (+ Neon)	Classic	Antique Brass with Black Insert	8
	3887136	2G 45A Cooker Ctrl (+ Neon)	Classic	Antique Brass with Black Insert	5
	3888100	2G 13A + USB 4.8A	Classic	Antique Brass with Black Insert	49
	3888121	1G 13A	Classic	Antique Brass with Black Insert	50
	3888122	1G 13A + USB	Classic	Antique Brass with Black Insert	189
	3888123	2G 13A	Classic	Antique Brass with Black Insert	143
	3888124	2G 13A + USB	Classic	Antique Brass with Black Insert	151
	3888125	1G Face Plate	Classic	Antique Brass with Black Insert	62
	3888126	2G Face Plate	Classic	Antique Brass with Black Insert	88
	3889127	1G 2W Dimmer	Classic	Antique Brass with Black Insert	44
	3889128	2G 2W Dimmer	Classic	Antique Brass with Black Insert	48
	3889129	4G 2W Dimmer	Classic	Antique Brass with Black Insert	7
	3889130	1G 2W Switch	Classic	Antique Brass with Black Insert	168
	3889131	2G 2W Switch	Classic	Antique Brass with Black Insert	193
	3889132	3G 2W Switch	Classic	Antique Brass with Black Insert	50

5	3889134	6G 2W Switch	Classic	Antique Brass with Black Insert	50
	3886217	1G 13A Unswitched FCU	Screw Less Plate	Black Nickel with Black Insert	9
	3886218	1G 13A Unswitched FCU + Neon	Screw Less Plate	Black Nickel with Black Insert	10
	3886219	1G 13A Switched FCU	Screw Less Plate	Black Nickel with Black Insert	9
	3886220	1G 13A Switched FCU + Neon	Screw Less Plate	Black Nickel with Black Insert	8
	3887215	1G 45A Switch (+ Neon)	Screw Less Plate	Black Nickel with Black Insert	5
	3887216	2G 45A Cooker Ctrl (+ Neon)	Screw Less Plate	Black Nickel with Black Insert	3
	3888200	2G 13A + USB 4.8A	Screw Less Plate	Black Nickel with Black Insert	48
	3888202	1G 13A + USB	Screw Less Plate	Black Nickel with Black Insert	8
	3888203	2G 13A	Screw Less Plate	Black Nickel with Black Insert	32
	3888204	2G 13A + USB	Screw Less Plate	Black Nickel with Black Insert	56
	3888205	1G Face Plate	Screw Less Plate	Black Nickel with Black Insert	35
	3888206	2G Face Plate	Screw Less Plate	Black Nickel with Black Insert	52
	3889207	1G 2W Dimmer	Screw Less Plate	Black Nickel with Black Insert	12
	3889208	2G 2W Dimmer	Screw Less Plate	Black Nickel with Black Insert	9
	3889209	4G 2W Dimmer	Screw Less Plate	Black Nickel with Black Insert	10
3889211	2G 2W Switch	Screw Less Plate	Black Nickel with Black Insert	7	
3889212	3G 2W Switch	Screw Less Plate	Black Nickel with Black Insert	9	
3889213	4G 2W Switch	Screw Less Plate	Black Nickel with Black Insert	4	
6	3886227	1G 13A Unswitched FCU	Flat Plate	Black Nickel with Black Insert	10
	3886228	1G 13A Unswitched FCU + Neon	Flat Plate	Black Nickel with Black Insert	10
	3886229	1G 13A Switched FCU	Flat Plate	Black Nickel with Black Insert	10
	3886230	1G 13A Switched FCU + Neon	Flat Plate	Black Nickel with Black Insert	10
	3887225	1G 45A Switch (+ Neon)	Flat Plate	Black Nickel with Black Insert	10
	3887226	2G 45A Cooker Ctrl (+ Neon)	Flat Plate	Black Nickel with Black Insert	4
	3888199	2G 13A + USB 4.8	Flat Plate	Black Nickel with Black Insert	2
	3888211	1G 13A	Flat Plate	Black Nickel with Black Insert	14
	3888212	1G 13A+USB	Flat Plate	Black Nickel with Black Insert	10
	3888213	2G 13A	Flat Plate	Black Nickel with Black Insert	37
	3888214	2G 13A + USB	Flat Plate	Black Nickel with Black Insert	45
	3888215	1G Face Plate	Flat Plate	Black Nickel with Black Insert	44
	3888216	2G Face Plate	Flat Plate	Black Nickel with Black Insert	28
3889217	1G 2W Dimmer	Flat Plate	Black Nickel with Black Insert	16	

1332

326

	3889218	2G 2W dimmer	Flat Plate	Black Nickel with Black Insert	19
	3889219	4G 2W Dimmer	Flat Plate	Black Nickel with Black Insert	10
	3889220	1G 2W Switch	Flat Plate	Black Nickel with Black Insert	1
	3889221	2G 2W Switch	Flat Plate	Black Nickel with Black Insert	8
	3889222	3G 2W Switch	Flat Plate	Black Nickel with Black Insert	14
	3889223	4G 2W Switch	Flat Plate	Black Nickel with Black Insert	4
	3889224	6G 2W Switch	Flat Plate	Black Nickel with Black Insert	3
7	3886237	1G 13A Unswitched FCU	Classic	Black Nickel with Black Insert	7
	3886238	1G 13A Unswitched FCU + Neon	Classic	Black Nickel with Black Insert	10
	3886239	1G 13A Switched FCU	Classic	Black Nickel with Black Insert	6
	3886240	1G 13A Switched FCU + Neon	Classic	Black Nickel with Black Insert	7
	3887235	1G 45A Switch (+ Neon)	Classic	Black Nickel with Black Insert	8
	3887236	2G 45A Cooker Ctrl (+ Neon)	Classic	Black Nickel with Black Insert	4
	3888221	1G 13A	Classic	Black Nickel with Black Insert	47
	3888222	1G 13A + USB	Classic	Black Nickel with Black Insert	1
	3888223	2G 13A	Classic	Black Nickel with Black Insert	8
	3888224	2G 13A + USB	Classic	Black Nickel with Black Insert	27
	3888225	1G Face Plate	Classic	Black Nickel with Black Insert	51
	3888226	2G Face Plate	Classic	Black Nickel with Black Insert	83
	3889227	1G 2W Dimmer	Classic	Black Nickel with Black Insert	8
	3889228	2G 2W Dimmer	Classic	Black Nickel with Black Insert	9
	3889229	4G 2W Dimmer	Classic	Black Nickel with Black Insert	10
	3889230	1G 2W Switch	Classic	Black Nickel with Black Insert	4
	3889231	2G 2W Switch	Classic	Black Nickel with Black Insert	13
	3889232	3G 2W Switch	Classic	Black Nickel with Black Insert	8
	3889233	4G 2W Switch	Classic	Black Nickel with Black Insert	2
	3889234	6G 2W Switch	Classic	Black Nickel with Black Insert	4
8	3885401	1G Intermediate Switch	Screw Less Plate	Brushed Chrome with Black Insert	70
	3885402	2G Intermediate Switch	Screw Less Plate	Brushed Chrome with Black Insert	40
	3885403	1G Blank Plate	Screw Less Plate	Brushed Chrome with Black Insert	40
	3885404	2G Blank Plate	Screw Less Plate	Brushed Chrome with Black Insert	40
	3885405	1G Coaxial	Screw Less Plate	Brushed Chrome with Black Insert	19
	3885407	1G Telecom Secondary	Screw Less Plate	Brushed Chrome with Black Insert	40

309

317

	3885408	1G Telecom Master	Screw Less Plate	Brushed Chrome with Black Insert	40
	3885409	Shaver Socket	Screw Less Plate	Brushed Chrome with Black Insert	20
	3885411	1G Data (Cat 6)	Screw Less Plate	Brushed Chrome with Black Insert	60
	3886418	1G 13A Unswitched FCU + Neon	Screw Less Plate	Brushed Chrome with Black Insert	10
	3886419	1G 13A Switched FCU	Screw Less Plate	Brushed Chrome with Black Insert	10
	3886420	1G 13A Switched FCU + Neon	Screw Less Plate	Brushed Chrome with Black Insert	49
	3886421	Fan Isolator	Screw Less Plate	Brushed Chrome with Black Insert	40
	3887415	1G 45A Switch (+ Neon)	Screw Less Plate	Brushed Chrome with Black Insert	50
	3887416	2G 45A Cooker Ctrl (+ Neon)	Screw Less Plate	Brushed Chrome with Black Insert	45
	3888400	2G 13A + USB 4.8A	Screw Less Plate	Brushed Chrome with Black Insert	49
	3888401	1G 13A	Screw Less Plate	Brushed Chrome with Black Insert	30
	3888402	1G 13A + USB	Screw Less Plate	Brushed Chrome with Black Insert	14
	3888403	2G 13A	Screw Less Plate	Brushed Chrome with Black Insert	668
	3888404	2G 13A + USB	Screw Less Plate	Brushed Chrome with Black Insert	32
	3888405	1G Face Plate	Screw Less Plate	Brushed Chrome with Black Insert	52
	3888406	2G Face Plate	Screw Less Plate	Brushed Chrome with Black Insert	40
	3889406	3G 2W Dimmer	Screw Less Plate	Brushed Chrome with Black Insert	45
	3889407	1G 2W Dimmer	Screw Less Plate	Brushed Chrome with Black Insert	35
	3889408	2G 2W Dimmer	Screw Less Plate	Brushed Chrome with Black Insert	40
	3889409	4G 2W Dimmer	Screw Less Plate	Brushed Chrome with Black Insert	55
	3889410	1G 2W Switch	Screw Less Plate	Brushed Chrome with Black Insert	13
	3889411	2G 2W Switch	Screw Less Plate	Brushed Chrome with Black Insert	56
	3889412	3G 2W Switch	Screw Less Plate	Brushed Chrome with Black Insert	34
	3889413	4G 2W Switch	Screw Less Plate	Brushed Chrome with Black Insert	34
	3889414	6G 2W Switch	Screw Less Plate	Brushed Chrome with Black Insert	5
9	3886427	1G 13A Unswitched FCU	Flat Plate	Brushed Chrome with Black Insert	10
	3886428	1G 13A Unswitched FCU + Neon	Flat Plate	Brushed Chrome with Black Insert	10
	3886429	1G 13A Switched FCU	Flat Plate	Brushed Chrome with Black Insert	5
	3886430	1G 13A Switched FCU + Neon	Flat Plate	Brushed Chrome with Black Insert	4
	3887425	1G 45A Switch (+ Neon)	Flat Plate	Brushed Chrome with Black Insert	9
	3887426	2G 45A Cooker Ctrl (+ Neon)	Flat Plate	Brushed Chrome with Black Insert	2
	3888399	2G 13A + USB 4.8A	Flat Plate	Brushed Chrome with Black Insert	45
	3888411	1G 13A	Flat Plate	Brushed Chrome with Black Insert	47

	3888412	1G 13A + USB	Flat Plate	Brushed Chrome with Black Insert	8
	3888413	2G 13A	Flat Plate	Brushed Chrome with Black Insert	14
	3888414	2G 13A + USB	Flat Plate	Brushed Chrome with Black Insert	14
	3888415	1G Face Plate	Flat Plate	Brushed Chrome with Black Insert	14
	3888416	2G Face Plate	Flat Plate	Brushed Chrome with Black Insert	28
	3889417	1G 2W Dimmer	Flat Plate	Brushed Chrome with Black Insert	15
	3889418	2G 2W Dimmer	Flat Plate	Brushed Chrome with Black Insert	10
	3889419	4G 2W Dimmer	Flat Plate	Brushed Chrome with Black Insert	9
	3889420	1G 2W Switch	Flat Plate	Brushed Chrome with Black Insert	29
	3889421	2G 2W Switch	Flat Plate	Brushed Chrome with Black Insert	15
	3889422	3G 2W Switch	Flat Plate	Brushed Chrome with Black Insert	5
	3889423	4G 2W Switch	Flat Plate	Brushed Chrome with Black Insert	2
	3889424	6G 2W Switch	Flat Plate	Brushed Chrome with Black Insert	5
10	3886437	1G 13A Unswitched FCU	Classic	Brushed Chrome with Black Insert	10
	3886438	1G 13A Unswitched FCU + Neon	Classic	Brushed Chrome with Black Insert	10
	3886439	1G 13A Switched FCU	Classic	Brushed Chrome with Black Insert	8
	3886440	1G 13A Switched FCU + Neon	Classic	Brushed Chrome with Black Insert	7
	3887435	1G 45A Switch (+ Neon)	Classic	Brushed Chrome with Black Insert	8
	3887436	2G 45A Cooker Ctrl (+ Neon)	Classic	Brushed Chrome with Black Insert	4
	3888421	1G 13A	Classic	Brushed Chrome with Black Insert	43
	3888422	1G 13A + USB	Classic	Brushed Chrome with Black Insert	3
	3888423	2G 13A	Classic	Brushed Chrome with Black Insert	164
	3888424	2G 13A + USB	Classic	Brushed Chrome with Black Insert	93
	3888425	1G Face Plate	Classic	Brushed Chrome with Black Insert	91
	3888426	2G Face Plate	Classic	Brushed Chrome with Black Insert	94
	3889427	1G 2W Dimmer	Classic	Brushed Chrome with Black Insert	3
	3889428	2G 2W Dimmer	Classic	Brushed Chrome with Black Insert	8
	3889429	4G 2W Dimmer	Classic	Brushed Chrome with Black Insert	10
	3889431	2G 2W Switch	Classic	Brushed Chrome with Black Insert	41
	3889432	3G 2W Switch	Classic	Brushed Chrome with Black Insert	49
	3889433	4G 2W Switch	Classic	Brushed Chrome with Black Insert	5
	3889434	6G 2W Switch	Classic	Brushed Chrome with Black Insert	4
11	3889307	1G 2W Dimmer	Screw Less Plate	Brushed Chrome with White Insert	5

300

655

	3889308	2G 2W Dimmer	Screw Less Plate	Brushed Chrome with White Insert	8
	3889309	4G 2W Dimmer	Screw Less Plate	Brushed Chrome with White Insert	10
	3889310	1G 2W Switch	Screw Less Plate	Brushed Chrome with White Insert	2
	3889311	2G 2W Switch	Screw Less Plate	Brushed Chrome with White Insert	4
	3889312	3G 2W Switch	Screw Less Plate	Brushed Chrome with White Insert	2
	3889313	4G 2W Switch	Screw Less Plate	Brushed Chrome with White Insert	5
	3889314	6G 2W Switch	Screw Less Plate	Brushed Chrome with White Insert	5
	3885305	1G Coaxial	Screw Less Plate	Brushed Chrome with White Insert	4
	3886318	1G 13A Unswitched FCU + Neon	Screw Less Plate	Brushed Chrome with White Insert	10
	3886319	1G 13A Switched FCU	Screw Less Plate	Brushed Chrome with White Insert	10
	3886320	1G 13A Switched FCU + Neon	Screw Less Plate	Brushed Chrome with White Insert	2
	3886321	Fan Isolator	Screw Less Plate	Brushed Chrome with White Insert	4
	3887315	1G 45A Switch (+ Neon)	Screw Less Plate	Brushed Chrome with White Insert	8
	3887316	2G 45A Cooker Ctrl (+ Neon)	Screw Less Plate	Brushed Chrome with White Insert	5
	3888300	2G 13A + USB 4.8A	Screw Less Plate	Brushed Chrome with White Insert	50
	3888302	1G 13A + USB	Screw Less Plate	Brushed Chrome with White Insert	21
	3888304	2G 13A + USB	Screw Less Plate	Brushed Chrome with White Insert	21
	3888305	1G Face Plate	Screw Less Plate	Brushed Chrome with White Insert	93
	3888306	2G Face Plate	Screw Less Plate	Brushed Chrome with White Insert	5
12	3886327	1G 13A Unswitched FCU	Flat Plate	Brushed Chrome with White Insert	10
	3886328	1G 13A Unswitched FCU + Neon	Flat Plate	Brushed Chrome with White Insert	10
	3886329	1G 13A Switched FCU	Flat Plate	Brushed Chrome with White Insert	10
	3886330	1G 13A Switched FCU + Neon	Flat Plate	Brushed Chrome with White Insert	10
	3887325	1G 45A Switch (+ Neon)	Flat Plate	Brushed Chrome with White Insert	10
	3887326	2G 45A Cooker Ctrl (+ Neon)	Flat Plate	Brushed Chrome with White Insert	4
	3888299	2G 13A + USB 4.8A	Flat Plate	Brushed Chrome with White Insert	46
	3888311	1G 13A	Flat Plate	Brushed Chrome with White Insert	25
	3888312	1G 13A + USB	Flat Plate	Brushed Chrome with White Insert	10
	3888313	2G 13A	Flat Plate	Brushed Chrome with White Insert	25
	3888314	2G 13A + USB	Flat Plate	Brushed Chrome with White Insert	24
	3888315	1G Face Plate	Flat Plate	Brushed Chrome with White Insert	43
	3888316	2G Face Plate	Flat Plate	Brushed Chrome with White Insert	28
	3889317	1G 2W Dimmer	Flat Plate	Brushed Chrome with White Insert	16

	3889318	2G 2W Dimmer	Flat Plate	Brushed Chrome with White Insert	9
	3889319	4G 2W Dimmer	Flat Plate	Brushed Chrome with White Insert	10
	3889320	1G 2W Switch	Flat Plate	Brushed Chrome with White Insert	10
	3889321	2G 2W Switch	Flat Plate	Brushed Chrome with White Insert	6
	3889322	3G 2W Switch	Flat Plate	Brushed Chrome with White Insert	4
	3889323	4G 2W Switch	Flat Plate	Brushed Chrome with White Insert	5
	3889324	6G 2W Switch	Flat Plate	Brushed Chrome with White Insert	5
13	3886337	1G 13A Unswitched FCU	Classic	Brushed Chrome with White Insert	10
	3886338	1G 13A Unswitched FCU + Neon	Classic	Brushed Chrome with White Insert	10
	3886339	1G 13A Switched FCU	Classic	Brushed Chrome with White Insert	9
	3886340	1G 13A Switched FCU + Neon	Classic	Brushed Chrome with White Insert	10
	3887335	1G 45A Switch (+ Neon)	Classic	Brushed Chrome with White Insert	7
	3887336	2G 45A Cooker Ctrl (+ Neon)	Classic	Brushed Chrome with White Insert	4
	3888323	2G 13A	Classic	Brushed Chrome with White Insert	21
	3888324	2G 13A + USB	Classic	Brushed Chrome with White Insert	15
	3888325	1G Face Plate	Classic	Brushed Chrome with White Insert	101
	3888326	2G Face Plate	Classic	Brushed Chrome with White Insert	85
	3889327	1G 2W Dimmer	Classic	Brushed Chrome with White Insert	11
	3889328	2G 2W Dimmer	Classic	Brushed Chrome with White Insert	9
	3889329	4G 2W Dimmer	Classic	Brushed Chrome with White Insert	10
	3889330	1G 2W Switch	Classic	Brushed Chrome with White Insert	6
	3889331	2G 2W Switch	Classic	Brushed Chrome with White Insert	42
	3889332	3G 2W Switch	Classic	Brushed Chrome with White Insert	1
	3889333	4G 2W Switch	Classic	Brushed Chrome with White Insert	3
14	3885603	1G Blank Plate	Screw Less Plate	Matt White Metal with White Insert	50
	3886617	1G 13A Unswitched FCU	Screw Less Plate	Matt White Metal with White Insert	90
	3886618	1G 13A Unswitched FCU + Neon	Screw Less Plate	Matt White Metal with White Insert	100
	3886619	1G 13A Switched FCU	Screw Less Plate	Matt White Metal with White Insert	80
	3886620	1G 13A Switched FCU + Neon	Screw Less Plate	Matt White Metal with White Insert	90
	3886621	Fan Isolator	Screw Less Plate	Matt White Metal with White Insert	40
	3887615	1G 45A Switch (+ Neon)	Screw Less Plate	Matt White Metal with White Insert	90
	3887616	2G 45A Cooker Ctrl (+ Neon)	Screw Less Plate	Matt White Metal with White Insert	92
	3888601	1G 13A	Screw Less Plate	Matt White Metal with White Insert	72

320

354

	3888602	1G 13A + USB	Screw Less Plate	Matt White Metal with White Insert	99
	3888603	2G 13A	Screw Less Plate	Matt White Metal with White Insert	133
	3888604	2G 13A + USB	Screw Less Plate	Matt White Metal with White Insert	27
	3888605	1G Face Plate	Screw Less Plate	Matt White Metal with White Insert	79
	3888606	2G Face Plate	Screw Less Plate	Matt White Metal with White Insert	79
	3889606	3G 2W Dimmer	Screw Less Plate	Matt White Metal with White Insert	44
	3889607	1G 2W Dimmer	Screw Less Plate	Matt White Metal with White Insert	90
	3889608	2G 2W Dimmer	Screw Less Plate	Matt White Metal with White Insert	94
	3889609	4G 2W Dimmer	Screw Less Plate	Matt White Metal with White Insert	45
	3889610	1G 2W Switch	Screw Less Plate	Matt White Metal with White Insert	50
	3889611	2G 2W Switch	Screw Less Plate	Matt White Metal with White Insert	60
	3889612	3G 2W Switch	Screw Less Plate	Matt White Metal with White Insert	85
	3889613	4G 2W Switch	Screw Less Plate	Matt White Metal with White Insert	88
	3889614	6G 2W Switch	Screw Less Plate	Matt White Metal with White Insert	95
15	3886517	1G 13A Unswitched FCU	Screw Less Plate	Polished Brass with Black Insert	10
	3886518	1G 13A Unswitched FCU + Neon	Screw Less Plate	Polished Brass with Black Insert	10
	3886519	1G 13A Switched FCU	Screw Less Plate	Polished Brass with Black Insert	10
	3886520	1G 13A Switched FCU + Neon	Screw Less Plate	Polished Brass with Black Insert	10
	3887515	1G 45A Switch (+ Neon)	Screw Less Plate	Polished Brass with Black Insert	10
	3887516	2G 45A Cooker Ctrl (+ Neon)	Screw Less Plate	Polished Brass with Black Insert	4
	3888500	2G 13A + USB 4.8A	Screw Less Plate	Polished Brass with Black Insert	4
	3888501	1G 13A	Screw Less Plate	Polished Brass with Black Insert	10
	3888502	1G 13A + USB	Screw Less Plate	Polished Brass with Black Insert	14
	3888503	2G 13A	Screw Less Plate	Polished Brass with Black Insert	7
	3888504	2G 13A + USB	Screw Less Plate	Polished Brass with Black Insert	7
	3888505	1G Face Plate	Screw Less Plate	Polished Brass with Black Insert	65
	3888506	2G Face Plate	Screw Less Plate	Polished Brass with Black Insert	42
	3889507	1G 2W Dimmer	Screw Less Plate	Polished Brass with Black Insert	13
	3889508	2G 2W Dimmer	Screw Less Plate	Polished Brass with Black Insert	5
	3889509	4G 2W Dimmer	Screw Less Plate	Polished Brass with Black Insert	9
	3889510	1G 2W Switch	Screw Less Plate	Polished Brass with Black Insert	5
	3889512	3G 2W Switch	Screw Less Plate	Polished Brass with Black Insert	5
	3889513	4G 2W Switch	Screw Less Plate	Polished Brass with Black Insert	5

16	3889514	6G 2W Switch	Screw Less Plate	Polished Brass with Black Insert	4
	3886527	1G 13A Unswitched FCU	Flat Plate	Polished Brass with Black Insert	10
	3886528	1G 13A Unswitched FCU + Neon	Flat Plate	Polished Brass with Black Insert	10
	3886529	1G 13A Switched FCU	Flat Plate	Polished Brass with Black Insert	7
	3886530	1G 13A Switched FCU + Neon	Flat Plate	Polished Brass with Black Insert	10
	3887525	1G 45A Switch (+ Neon)	Flat Plate	Polished Brass with Black Insert	10
	3887526	2G 45A Cooker Ctrl (+ Neon)	Flat Plate	Polished Brass with Black Insert	5
	3888499	2G 13A + USB 4.8A	Flat Plate	Polished Brass with Black Insert	50
	3888513	2G 13A	Flat Plate	Polished Brass with Black Insert	44
	3888514	2G 13A + USB	Flat Plate	Polished Brass with Black Insert	49
	3888515	1G Face Plate	Flat Plate	Polished Brass with Black Insert	59
	3888516	2G Face Plate	Flat Plate	Polished Brass with Black Insert	8
	3889517	1G 2W Dimmer	Flat Plate	Polished Brass with Black Insert	12
	3889518	2G 2W Dimmer	Flat Plate	Polished Brass with Black Insert	4
	3889520	1G 2W Switch	Flat Plate	Polished Brass with Black Insert	6
	3889521	2G 2W Switch	Flat Plate	Polished Brass with Black Insert	3
3889522	3G 2W Swich	Flat Plate	Polished Brass with Black Insert	5	
3889523	4G 2W Switch	Flat Plate	Polished Brass with Black Insert	4	
3889524	6G 2W Switch	Flat Plate	Polished Brass with Black Insert	2	
17	3886537	1G 13A Unswitched FCU	Classic	Polished Brass with Black Insert	8
	3886538	1G 13A Unswitched FCU + Neon	Classic	Polished Brass with Black Insert	10
	3886539	1G 13A Switched FCU	Classic	Polished Brass with Black Insert	10
	3886540	1G 13A Switched FCU + Neon	Classic	Polished Brass with Black Insert	7
	3887535	1G 45A Switch (+ Neon)	Classic	Polished Brass with Black Insert	8
	3887536	2G 45A Cooker Ctrl (+ Neon)	Classic	Polished Brass with Black Insert	4
	3888521	1G 13A	Classic	Polished Brass with Black Insert	48
	3888523	2G 13A	Classic	Polished Brass with Black Insert	3
	3888524	2G 13A + USB	Classic	Polished Brass with Black Insert	194
	3888525	1G Face Plate	Classic	Polished Brass with Black Insert	86
	3888526	2G Face Plate	Classic	Polished Brass with Black Insert	65
	3889527	1G 2W Dimmer	Classic	Polished Brass with Black Insert	1
	3889528	2G 2W Dimmer	Classic	Polished Brass with Black Insert	13
3889529	4G 2W Dimmer	Classic	Polished Brass with Black Insert	9	

249

298

3889531	2G 2W Switch	Classic	Polished Brass with Black Insert	7
3889532	3G 2W Switch	Classic	Polished Brass with Black Insert	13
3889533	4G 2W Switch	Classic	Polished Brass with Black Insert	3
3889534	6G 2W Switch	Classic	Polished Brass with Black Insert	4